



LAUNDERING ECO-LUXE LINEN – PROGRAMMABLE MACHINES

BREAK/SUDS CYCLE:

10 Minutes
 Hot water, 160-170°
 low water level
 (ALKALI at 300 ppm)

RINSE 1:	RINSE 2:	RINSE 3:	FINAL RINSE:
2 minutes	2 minutes	2 minute	4 minutes
warm water, 140°	warm water, 120°	cold water, 80° to 85°	cold water, 80° to 85°
high level	high level	high level	low level

EXTRACT:

1 or 2 minutes
 slow speed

DRYING:

15 minutes
 medium heat temperature (130° to 140°)
 5 minutes
 cool down
remove from dryer immediately when done

Please note there may be a small amount of microfiber lint after the first and second wash. This is perfectly normal.

*All product amounts are based on 100lbs. of washer capacity.

IRONING/FOLDING FOR SHEETS:

Sheets do not need to be pressed if they are removed from dryer and folded promptly.

If you prefer to put through an ironer. We recommend putting the sheets through the ironer at the temperature of 340 Degrees at a speed of 110 FPM. Adjustments may be made depending on the machine being used.

For optimal results:

Only launder products in a FULL load.

Wash as soon as possible. Do not let soiled goods sit overnight. If they must sit overnight, bag the soiled goods in plastic bags to keep the air from oxidizing the spa oils which makes the oils MUCH more difficult to remove.

Do not use bleaches, as bleach will oxidize Spa oils making it more difficult to remove.